

## #52020/92020 The Corner Place Dollhouse Kit

Step-by-step assembly instructions

Copyright miniatures.com 2020, 2024

### MDF PARTS:

Left wall (large window opening)  
Right wall (door opening)  
Floor  
Platform  
Floor edge support/trim (2)  
End panel/platform support  
Platform edge trim (2)

### WHITEWOOD PARTS:

Preassembled step unit  
Platform support legs (3)  
Step support brace  
Door  
Large window  
Small window  
Trim for door and windows

### SUPPLIES NEEDED:

Masking tape  
White glue (such as #1249 Weldbond)  
Ruler  
Pencil



### GENERAL INSTRUCTIONS

- Identify and inspect all parts using the Parts List.
- Thoroughly read the directions before starting.
- Set up a dedicated work area to avoid the need to unpack, repack, or move the project frequently.
- Use a clean, level, and dry work surface protected from glue spills.
- Dry fit the parts using masking tape to ensure everything aligns correctly before permanent assembly.

## Assembly Instructions

Tip: Plan the finishes for the interior and exterior at the dry-fit stage, before final/permanent assembly. It is easier to finish the panels as flat surfaces. Disassemble and finish as desired, then reassemble using glue.

As you plan your project, keep in mind that the steps and all platform supports may be used in any location; the platform edge trim is provided to create a more substantial appearance but is not required; and that the door opening is a standard size if you prefer a different style.

1. Place left wall on work surface with grooved side up and floor groove near you. Place right wall at right, fitting into rabbet and matching floor groove. Fit floor into grooves on both walls, square up edges and tape securely.
2. Fit floor edge trim/support pieces to outside edges of floor and join the mitered corner. Tape securely. Set assembly upright.
3. Using a gluing jig or other method to assure a square join, glue the step support brace between two of the platform support legs, flush at the top and forming an upside-down U assembly. (This assembly is necessary to support the steps and will not need to be taken apart so may be glued right away.)
4. Fit the platform into its groove and square to the right wall. Use the remaining platform support leg and/or the end panel/platform support to keep the platform level. Tape securely.
5. When the glued step support assembly is dry, fit it in place at the front edge of the platform and rest the step unit against the posts so that it is flush against the floor and the posts.