∂miniatures.com™

#73098 Canopy Instructions

Step-by-step assembly instructions Copyright miniatures.com 2023

SUPPLIES NEEDED:

Clear drying craft glue Graph paper Pin (or any pointed sharp instrument) Small sharp scissors (or any sharp cutting instrument)

Assembly Instructions

Installing Bed Posts

- 1. Add glue into the two post sockets on either side of the headboard.
- 2. Insert a post into each post socket.
- 3. Place the bed frame upright with the headboard and two posts flat on the work surface. Align the posts at a right angle to the headboard. Working on graph paper can help assure that the assembly is square.
- 4. Let the glue dry.
- 5. Repeat Steps 1-4 for the remaining two posts.
- 6. Let the glue dry.

Installing Canopy Finials*

- 7. Find the hole in each of the four corners of the canopy frame.
- From the underside of the canopy, press a pin through a hole in the canopy frame and through the canopy fabric. Lightly mark, on the top side of the canopy fabric the pin's location.
- 9. Repeat Step 8 for all three other holes in the canopy frame.

- Make a very small incision (≤1/8") in the fabric at the mark.
- 11. Press a finial through the incision into the hole in the canopy frame.
- 12. Repeat Steps 10-11 for all three other finials.
- Remove all the finials, add glue into all fabric-canopy holes and reinsert the finals.
- 14. Let the glue dry.

Mounting Canopy on Posts

- 15. Add glue to the bottom of each finial.
- Place the canopy on top of the bed posts and insert the bottom of each finial into the top of each corresponding post.
- 17. Let the glue dry.

*If the canopy fabric has wrinkled during transit, you may want to use a steamer to freshen it before installing.

> WARNING: CHOKING HAZARD – Small parts Not for children under 3 yrs. Adult supervision required.