

The Instruction of DIY House Dust Cover

This product is made of high polymer and ultra-permeable acrylic material, which contains 6 pieces of panels (including 4 sides plates, 1 top plate and 1 bottom plate). With the exception of the bottom plate, all have full angles transparent viewing effect. This product adopts the combination structure of card mount and board, which has good cohesion. It does not need tools, easy to install and firm stitching. It can make the model of DIY House free from dust and more valuable to collect, and it's also a perfect gift for family and friends.

Product list

Top plate: transparent acrylic, four sides are even concave grooves.

Side plate: transparent acrylic, three sides have concave grooves, one side is straight edge without concave grooves.

Bottom plate: Solid wood.

Notice

Note: Peel off the clear protective sheet covers on both sides of the panels before assembly.




Do not force to insert, to avoid the collapse of the side or broken angle of the acrylic dust cover. If you are unable to insert, please use a small file to polish the concave and convex edge.

Assembly Instructions

Parts:6 pcs


1



· Take out the bottom plate and put it on the table.
Notice the grooves side is on top


2

· Insert the front and back side plates into the corresponding grooves.




3

- Insert the left and right side plates into the corresponding grooves. Note: Insert all plates to the bottom of the grooves as shown




4




Match the slots and press the plates from the bottom

Assembly illustration:



- Connect the plates as shown. (Note: Push with proper force to avoid breaking)
- Match the slots on the four side plates. Gently press them from bottom to top to connect.

5



- Match the slots of the top and side plates and connect them.